
INSTALLATION INSTRUCTIONS



Variable Column Display Interface



FCAVCA

FCAVCA Installation Instructions

DISCLAIMER

Legrand | AV and its affiliated corporations and subsidiaries (collectively "Legrand | AV"), intend to make this manual accurate and complete. However, Legrand | AV makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Legrand | AV makes no representation of warranty, expressed or implied, regarding the information contained herein. Legrand | AV assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

DEFINITIONS

MOUNTING SYSTEM: A MOUNTING SYSTEM is the primary Chief product to which an accessory and/or component is attached.

ACCESSORY: AN ACCESSORY is the secondary Chief product which is attached to a primary Chief product, and may have a component attached or setting on it.

COMPONENT: A COMPONENT is an audiovisual item designed to be attached or resting on an accessory or mounting system such as a video camera, CPU, screen, display, projector, etc.

WARNING: A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.

CAUTION: A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.



IMPORTANT SAFETY INSTRUCTIONS

WARNING: Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure al accessories are properly assembled and installed using the instructions provided.

WARNING: Failure to provide adequate structural strength for this accessories can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the structure to which this accessory is attached can support five times the combined weight of all equipment. Reinforce the structure as required before installing the accessory.

WARNING: Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components attached to accessory does not exceed the weight limit of the mount to which it is attached.

WARNING: Use this accessory only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

WARNING: Never operate this accessory if it is damaged. Return the accessory to a service center for examination and repair.


WARNING: Do not use this accessory outdoors.

IMPORTANT!: The FCAVCA accessory is designed to be mounted to a truss column using the FCAVCSU80 8" square U-bolts accessory or a pole column using the FCAVCSU20 2" clamping U-bolts accessory.


-- SAVE THESE INSTRUCTIONS--

Installation Instructions FCAVCA

DIMENSIONS




LEGEND




Installation Instructions FCAVCA

TOOLS REQUIRED FOR INSTALLATION



PARTS



Assembly And Installation

 Install cage nuts (AA or BA) to appropriate holes on mounting plate (C) depending on what mount will be installed. (See Figure 1)





Figure 1

 Install mounting plate (C) onto column or pipe referring to installation instructions for (FCAVCSU80 or FCAVCSU20) mounting accessory.

Thinstall Mounts (TS118/218/318) and FMSWM

NOTE: If installing to MTMS1U/MTMP1U/MTM1U/MSM1U/LTM1U/LSM1U, proceed to MTMS1U/MTMP1U/MTM1U/MSM1U/LTM1U/LSM1U section.


- Loosely install appropriate hardware (AA and AB) or (BA and BB) to upper cage nut installed in Step 1. (See Figure 2) or (See Figure 3) or (See Figure 4) or (See Figure 5)
- Hang mount onto loosely installed screw and tighten screw. (See Figure 2) or (See Figure 3) or (See Figure 4) or (See Figure 5)
- 5. Use appropriate hardware (AA and AB) or (BA and BB) to secure mount to lower cage nut installed in Step 1. (See Figure 2) or (See Figure 3) or (See Figure 4) or (See Figure 5)



TS218SU (BB) (BC) (BC) (BC) (BC) (BB)

Figure 3

Installation Instructions FCAVCA



MTMS1U

(AB) x 4

(AC) x 4

Figure 4




Figure 5

MTMS1U/MTMP1U/MTM1U/MSM1U/LTM1U/LSM1U

6. Use two or four 5/16-18 x 7/8" button head cap screws (AA) and two or four .750x.350x.060 spacers (AB) to secure mount to top cage nuts installed in Step 1. (See Figure 6) or (See Figure 7)

Figure 6




Figure 7

7. Install display to mount following installation instructions for each mount.

FCAVCA Installation Instructions



A brand of Lilegrand

8800-003120 Rev01 ©2020 Legrand | AV www.legrandav.com 03/20

Europe

USA/International A 6436 City West Parkway, Eden Prairie, MN 55344

800.582.6480 / 952.225.6000

F 877.894.6918 / 952.894.6918

A Franklinstraat 14, 6003 DK Weert, Netherlands

+31 (0) 495 580 852

+31 (0) 495 580 845

Asia Pacific A Office No. 918 on 9/F, Shatin Galleria

18-24 Shan Mei Street

Fotan, Shatin, Hong Kong

P 852 2145 4099

F 852 2145 4477

